




# Kit 1594

**SKODA Octavia**, 4-dr Sedan, 04-08, 09–  
**SKODA Octavia**, 5-dr Hatchback, 04-08, 09–



**754** Rapid System  
**480R** Rapid Traverse (North America)



**480** Traverse (North America)



**754 Rapid System**  
**480R Rapid Traverse (North America)**

---

**754 Rapid System**  
**480R Rapid Traverse (North America)**

---

**480 Traverse (North America)**

(North America)

- Component 1: x2
- Component 2: x2 (23 mm)
- Component 3: x2 (23 mm)
- Component 4: x4
- Component 5: x4
- Component 6: x1 (17 mm)
- Component 7: x2 (23 mm)
- Component 8: x2
- Component 9: x2
- Component 10: x2
- Component 11: x2 (23 mm)
- Component 12: x2

- Component 1: x2 (179)
- Component 2: x2 (181)
- Component 3: x1 (661)
- Component 4: x1 (673)
- Component 5: x1 (1091)
- Component 6: x1 (1092)
- Component 7: x1 (Diagram with RR, FR, FL, RL labels)

1





2






754 Rapid System  
480R Rapid Traverse  
(North America)



x4





x4



x4



480 Traverse  
(North America)



x4

**3**



**754** Rapid System



	<b>X</b>
<b>SKODA Octavia, 4-dr Sedan, 04-08, 09-</b>	<b>33</b>
<b>SKODA Octavia, 5-dr Hatchback, 04-08, 09-</b>	<b>33</b>



	<b>Y</b>
<b>SKODA Octavia, 4-dr Sedan, 04-08, 09-</b>	<b>29,5</b>
<b>SKODA Octavia, 5-dr Hatchback, 04-08, 09-</b>	<b>29,5</b>

**3**




**480R** Rapid Traverse




**480** Traverse



**(North America)**



	<b>X inch</b>	<b>X mm</b>
<b>SKODA Octavia, 4-dr Sedan, 04-08, 09-</b>	<b>38 <sup>5</sup>/<sub>8</sub> "</b>	<b>981 mm</b>
<b>SKODA Octavia, 5-dr Hatchback, 04-08, 09-</b>	<b>38 <sup>5</sup>/<sub>8</sub> "</b>	<b>981 mm</b>





	<b>Y inch</b>	<b>Y mm</b>
<b>SKODA Octavia, 4-dr Sedan, 04-08, 09-</b>	<b>37 <sup>1</sup>/<sub>4</sub> "</b>	<b>946 mm</b>
<b>SKODA Octavia, 5-dr Hatchback, 04-08, 09-</b>	<b>37 <sup>1</sup>/<sub>4</sub> "</b>	<b>946 mm</b>

**4**




# 5




SKODA Octavia, 4-dr Sedan, 04-08, 09-  
 SKODA Octavia, 5-dr Hatchback, 04-08, 09-



6



	X mm	Y mm	X inch	Y inch
SKODA Octavia, 4-dr Sedan, 04-08, 09–	450 mm	740 mm	17 3/4"	29 1/8"
SKODA Octavia, 5-dr Hatchback, 04-08, 09–	450 mm	740 mm	17 3/4"	29 1/8"



7



GB/US Tighten alternately  
 D Die Schrauben abwechselnd anziehen  
 F Serrer alternativement chaque côté  
 NL Afwisselend aan de linker- en de rechterkant aandraaien  
 I Alternare il serraggio delle viti  
 E Apertar alternativamente  
 PT Aperte alternadamente  
 S Dra åt växelvis  
 FIN Kierrä vuorotellen  
 EST Pinguldage vaheldumisi  
 LAT Pieļieciet pamišus  
 LIT Užsukinėkite pakaitomis  
 PL Śruby dokręcaj naprzemiennie  
 RU Затягивайте попеременно


CZ Pокрѣtla багажníka dokręcaj naprzemiennie.  
 SK Dofahajte striedavo  
 SLO Privijajte izmenično.  
 HR Naizmjenočno zategnite  
 HU Egymástól függetlenül szorítandó  
 GR Σφιγίγεται εναλλάξ  
 TR Dönüşümlü sıkın

中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。



ไทย ชันในแบบสลับ



8



x1  
17 mm






**THULE**  
SWEDEN  
**ONE  
KEY  
SYSTEM**



- 544 (x4)
  - 596 (x6)
  - 588 (x8)
  - 510 (x10)
  - 452 (x12)
- NA  
EUR  
ASIA



WW ▶ Thule Sweden AB, Box 69, 330 33 Hillerstorp, SWEDEN  
NA ▶ Thule Inc., 42 Silvermine Road, Seymour, Connecticut 06483, USA

info@thule.com  
customer.service@thule.com

www.thule.com